



92798 Cape Arago Hwy  
Coos Bay, OR 97420  
Phone (541) 888-3517  
Fax (541) 888-4846  
www.kksound.com

## DUAL CHANNEL PRO PREAMP



The Dual Channel Pro Preamp is an extremely powerful yet small dual-channel mixer in a belt clip box. It is designed for mixing two inputs: pickup/pickup, pickup/microphone, or two instruments. It offers volume, gain, and 3-band EQ controls for each channel.

The tone controls feature an extended range of +/- 20 dB, which exceeds many mixers on the market today. To keep the box as small as possible, the gain and tone controls are trim pots inside the unit (small potentiometers for adjustment with a supplied screwdriver). During a performance, you can conveniently balance the two channels on the volume control knobs.

**Before first use, please insert a 9-volt battery. To switch the battery off, always unplug the MAIN/MIX OUT jack.**

### Setting up your Preamp:

1. Open the black screw and remove the lid. Insert battery into designated compartment.
2. On the inside of the lid is a diagram for the internal trim pot controls. In the box you will find a small screwdriver for the adjustment of the trim pots. It is attached with a Velcro fastener.
3. Connect your pickups to the two inputs and connect the output via a **mono** ¼" guitar cable to an amplifier or mixing board.
4. Set your amp to a flat setting first. Adjust the gain trim pots of each individual channel until both channels are at about the same volume. Adjust EQ trim pots to your preference. Close the lid and you are ready to go.

### Technical Data

Frequency response: 10 - 30,000 Hz  
Inputs: 1 Mega Ohm  
Output: 10 Kilo Ohm  
Battery consumption: 3 Milli Amp, about 60 hours

